



STD CRUSH User Manual & Maintenance



Thank you for purchasing one of our range of Cattle Handling Equipment.

Norton Gates has been manufacturing and developing their crushes since 1992.

We trust that our user and maintenance manual is full of helpful information that will prolong the life of your equipment.

If you have any difficulties after referring to this guide, please do not hesitate to contact us.



NORTON GATES PTY LTD

1939 Frankston Flinders Road
Hastings
Victoria, 3915

Norton Gates Pty Ltd
1939 Frankston Flinders Road
HASTINGS VIC 3915
PH: 03 5979 1053
FAX: 03 5979 3878

www.nortongates.com.au
sales@nortongates.com.au



CATTLE CRUSH INSTALLATION

Crush should be bolted to a concrete slab no less than 100mm thick, using dyna bolts or the like,
STD CRUSHES have 4 fixing points at base and
VET CRUSHES have six.

We recommend that the concrete slab size is

STD CRUSH

3mts long x 2.8mts wide

VET CRUSH

4mts long x 2.8mts wide

The width of can be reduced to 1.2mts but at 2.8mts this allows you approximately

1mts each side to have a solid, safe and clean base to work on.

Crush sitting on earth surface can reduce crush life due to corrosion & is unstable to work with.

BASIC CRUSH MAINTENANCE

LUBRICATION

Always keep all moving parts well lubricated to prevent seizing, this includes slam shut latches & side gate hinges. All pivot and bolt points on the head bail should be regularly sprayed with an aerosol lubricant to ensure smooth working of head bail.

BOLTS

All bolts should be regularly checked for correct tightness. Bolts should be tightened firmly so that the bolts do not slop in the bolt-hole, but should not be over-tightened to cause restrictive movement of the head bail. Worn bolts should be replaced immediately.

CLEANING

After each use crush should be washed down and all parts re-lubricated. This will help with rust prevention while not in use.

WARRANTY

Norton Gates products are covered by a 12 month warranty on all workmanship. We do not accept any responsibility for breakages, malfunctions or injury due to misuse of product.

Due to our policy of continuous product development, we reserve the right to alter specifications where appropriate and without notice.

Crushes modified outside or by other parties other than Norton Gates Pty Ltd, will forfeit their Warranty.